



ETHANOL GAS STANDARD CYLINDER REPORT

OFFICE OF ATTORNEY GENERAL

CRIME LABORATORY DIVISION

Toxicology Section/Breath Alcohol Program

SFN 59282 (10-2013)

Chemical Test Operator Name (Print) Collins, Travis L.		
Location HETT	Intoxilyzer® Serial Number 80-004952	
Gas Lot Number 29614080A2	Gas Cylinder Number 34	Gas Expiration Date 12/05/2016

Check When Done:

- 1. Scan/Enter Gas Cylinder Information (Level 1, Function S).
- 2. Perform an ACA Test (Level 1, Function C).
Write in the ACA Test Results (Reported to 3 Digits, Ex. 0.081).
 - A. 0.079 AC
 - B. 0.080 AC
 - C. 0.080 AC
- 3. Complete the Top Portion of the Intoxilyzer® Record (SFN50496, Form 120-G) and Place it by the Intoxilyzer® for Use.
- 4. File Previous Intoxilyzer® Record (SFN50496, Form 120-G) at the Intoxilyzer® Location at the Agency.
- 5. Send the Following to the Crime Laboratory:
 - A. Ethanol Gas Standard Cylinder Report (SFN59282, Form 105-G).
 - B. ACA Test Record.

Chemical Test Operator Signature <i>T Collins</i>	Date 01/15/2016
Reviewed By (Crime Laboratory Use Only) <i>Deb Shanaver</i>	Date 21-Jan-16

Intoxilyzer Test Record and Checklist
NDOAG Crime Lab. Div., Bismarck, ND 58501

CMI, Inc. Intoxilyzer Alcohol Analyzer
North Dakota Model 8000 SN 80-004952
Location = HETT 8164.13.00 06/09
01/15/2016 20:50

DRY CAL CHECK

Test	AC	Time
01 Room Air	0.000	20:51
02 Std. Gas	0.079	20:51
03 Room Air	0.000	20:52
04 Std. Gas	0.080	20:52
05 Room Air	0.000	20:53
06 Std. Gas	0.080	20:53
07 Room Air	0.000	20:54

Lot No = 29614080A2

Cyl No = 34

Exp Date = 12/05/2016

County = 01

Oper No. = 020533



Operator Signature
TRAVIS COLLINS

Remarks:

Form 106-I8000