



ETHANOL BREATH STANDARD CYLINDER REPORT
 OFFICE OF ATTORNEY GENERAL
 CRIME LABORATORY DIVISION
 Toxicology Section/Breath Alcohol Program
 SFN 59282 (5-2011)

Chemical Test Operator Name (Print) <i>Chad L. Harmon</i>		
Location <i>FYPD</i>	Intoxilyzer® Serial Number <i>80-004193</i>	
Gas Lot Number <i>10512080A2</i>	Gas Cylinder Number <i>25</i>	Gas Expiration Date <i>08-01-2014</i>

Check When Done:

- 1. Scan/Enter Gas Cylinder Information (Level 1, Function S).
- 2. Perform an ACA Test (Level 1, Function C).
 Write in the ACA Test Results (Reported to 3 Digits, Ex. 0.081).
 - A. 0. 079 AC
 - B. 0. 080 AC
 - C. 0. 079 AC
- 3. Complete the Top Portion of the Intoxilyzer® Record (SFN50496, Form 120-G) and Place it by the Intoxilyzer® for Use.
- 4. File Previous Intoxilyzer® Record (SFN50496, Form 120-G) at the Intoxilyzer® Location at the Agency.
- 5. Send the Following to the Crime Laboratory:
 - A. Ethanol Breath Standard Cylinder Report (SFN59282, Form 105-G).
 - B. ACA Test Record.

Chemical Test Operator Signature <i>[Signature]</i>	Date <i>04-05-2014</i>
Reviewed By (Crime Laboratory Use Only) <i>Roberta Huegel-Humm</i>	Date <i>09-07-2017</i>

NOTE: The form 105-G was revised 10-2013, but this gas cylinder install was not received until more than 3 years had passed since the test was ran. ResN 09-07-2017.

Intoxilyzer Test Record and Checklist
NDOAG Crime Lab. Div., Bismarck, ND 58501

CMI, Inc. Intoxilyzer Alcohol Analyzer
North Dakota Model 8000 SN 80-004193
Location = FYPD 8164.13.00 06/09
04/05/2014 16:21

DRY CAL CHECK

Test	AC	Time
01 Room Air	0.000	16:22
02 Std. Gas	0.079	16:22
03 Room Air	0.000	16:23
04 Std. Gas	0.080	16:23
05 Room Air	0.000	16:24
06 Std. Gas	0.079	16:24
07 Room Air	0.000	16:25

Lot No = 16512080A2
Cyl No = 25
Exp Date = 08/01/2014
County = 61 Oper No. = 010606



Operator Signature
CHAD HARMON

Remarks: