



ETHANOL GAS STANDARD CYLINDER REPORT
 NORTH DAKOTA OFFICE OF ATTORNEY GENERAL
 CRIME LABORATORY DIVISION-TOXICOLOGY SECTION/BREATH ALCOHOL PROGRAM
 SFN 59282 (08/2018)

Chemical Test Operator Name (Print) <i>Eric Braathen</i>		
Location <i>killdeer PD</i>	Intoxilyzer® Serial Number <i>80-006493</i>	
Gas Lot Number <i>2411908A1</i>	Gas Cylinder Number <i>014</i>	Gas Expiration Date <i>11-15-2021</i>

Check When Done:

- 1. Scan/Enter Gas Cylinder Information (Level 1, Function S).
- 2. Perform an ACA Test (Level 1, Function C).
 Write in the ACA Test Results (Reported to 3 Digits, Ex. 0.081).
 A. *0.082* AC *CEE 3/4/20*
 B. *0.082* AC *REC'D ACA TEST (DRY CAL CHECK)*
 C. *0.082* AC
- 3. Complete the Top Portion of the Intoxilyzer® Record (SFN50496, Form 120-G) and Place it by the Intoxilyzer® for Use.
- 4. File Previous Intoxilyzer® Record (SFN50496, Form 120-G) at the Intoxilyzer® Location at the Agency.
- 5. Send the Following to the Crime Laboratory:
 - A. Ethanol Gas Standard Cylinder Report (SFN59282, Form 105-G).
 - B. ACA Test Record.

*OS
CEE
3/4/20*

Chemical Test Operator Signature <i>Eric Braathen</i>	Date <i>3-4-20</i>
Reviewed By (Crime Laboratory Use Only) <i>Charles E. Ed</i>	Date <i>3/4/20</i>

Intoxilyzer Test Record and Checklist
NDOAG Crime Lab. Div., Bismarck, ND 58501

CMI, Inc. Intoxilyzer Alcohol Analyzer
North Dakota Model 8000 SN 80-006493
Location = KDPD 8164.14.00 09/16
03/04/2020 13:05

DRY CAL CHECK

Test	AC	Time
01 Room Air	0.000	13:06
02 Std. Gas	0.082	13:06
03 Room Air	0.000	13:07
04 Std. Gas	0.082	13:07
05 Room Air	0.000	13:08
06 Std. Gas	0.082	13:08
07 Room Air	0.000	13:09

Lot No = 24119080A1
Cyl No = 14
Exp Date = 11/05/2021
County = 13 Oper No. = 100444

Eric Braathen

Operator Signature
ERIC BRAATHEN

Remarks:

Form 106-I8000