

ETHANOL GAS STANDARD CYLINDER REPORT NORTH DAKOTA OFFICE OF ATTORNEY GENERAL CRIME LABORATORY DIVISION-TOXICOLOGY SECTION/BREATH ALCOHOL PROGRAM SFN 59282 (08/2018)

Chemical Test Operator Name (Print)				
JEREMIAH BOHN		· · · · · · · · · · · · · · · · · · ·		
Location	Intoxilyzer® Serial Number			
WARD COUNTY JAIL	8	30-006677		
Gas Lot Number Gas Cylinder	r Number	Gas Expiration Date		
026210B0A1	0	3/5/2023		

Check When Done:

- 1. Scan/Enter Gas Cylinder Information (Level 1, Function S).
- 2. Perform an ACA Test (Level 1, Function C).

Write in the ACA Test Results (Reported to 3 Digits, Ex. 0.081).

- A. 0.2 81 AC
- B. 0.08 2 AC
- C. 0282 AC

Z 3. Complete the Top Portion of the Intoxilyzer® Record (SFN50496, Form 120-G) and Place it by the Intoxilyzer® for Use.

4. File Previous Intoxilyzer® Record (SFN50496, Form 120-G) at the Intoxilyzer® Location at the Agency.

5. Send the Following to the Crime Laboratory:

- A. Ethanol Gas Standard Cylinder Report (SFN59282, Form 105-G).
- B. ACA Test Record.

Chemical Test Operator Signature	Date 9/14/2021
Reviewed By (Crime Laboratory Use Only)	Date 9.14.2021

Intoxilyzer Test Record and Checklist NDOAG Crime Lab. Div., Bismarck, ND 58501

CMI, Inc. IntoxilyzerAlcohol AnalyzerNorth Dakota Model 8000SN 80-006677Location = WARD8164.14.00 09/1609/14/202110:21

	DRY CAL CHECK	
Test	AC	Time
01 Room Air	0.000	10:22
02 Std. Gas	0.081	10:22
03 Room Air	0.000	10:23
04 Std. Gas	0.080	10:23
05 Room Air	0.000	10:24
06 Std. Gas	0.080	10:24
07 Room Air	0.000	10:25
Lot No = 0262	21080A1	

Cyl No = 8 Exp Date = 03/05/2023County = 51 Oper No. = 050702

Operator Signature JEREMIAH BOHN

Remarks:

PASSED

Form 106-18000