



ETHANOL BREATH STANDARD CYLINDER REPORT

OFFICE OF ATTORNEY GENERAL

CRIME LABORATORY DIVISION

Toxicology Section/Breath Alcohol Program

SFN 59282 (5-2011)

Chemical Test Operator Name (Print) <i>Lori Flaten</i>		
Location <i>Mandan PD</i>	Intoxilyzer® Serial Number <i>80-004939</i>	
Gas Lot Number <i>659358</i>	Gas Cylinder Number <i>40</i>	Gas Expiration Date <i>09-03-11</i>

Check When Done:

- 1. Scan/Enter Gas Cylinder Information (Level 1, Function S).
- 2. Perform an ACA Test (Level 1, Function C).
Write in the ACA Test Results (Reported to 3 Digits, Ex. 0.081).
 - A. 0. 081 AC
 - B. 0. 080 AC
 - C. 0. 081 AC
- 3. Complete the Top Portion of the Intoxilyzer® Record (SFN50496, Form 120-G) and Place it by the Intoxilyzer® for Use.
- 4. File Previous Intoxilyzer® Record (SFN50496, Form 120-G) at the Intoxilyzer® Location at the Agency.
- 5. Send the Following to the Crime Laboratory:
 - A. Ethanol Breath Standard Cylinder Report (SFN59282, Form 105-G).
 - B. ACA Test Record.

Chemical Test Operator Signature <i>[Signature]</i>	Date <i>05-18-11</i>
Reviewed By (Crime Laboratory Use Only) <i>Deb Kashur</i>	Date <i>20 May 2011</i>

*80-004939
P. 62 of 63
SM*

Intoxilyzer Test Record and Checklist
NDOAG Crime Lab. Div., Bismarck, ND 58501

CMI, Inc. Intoxilyzer Alcohol Analyzer
North Dakota Model 8000 SN 80-004939
Location = MAND 8164.13.00 06/09
05/18/2011 15:21

DRY CAL CHECK

Test	AC	Time
01 Room Air	0.000	15:21
02 Std. Gas	0.081	15:22
03 Room Air	0.000	15:22
04 Std. Gas	0.080	15:23
05 Room Air	0.000	15:23
06 Std. Gas	0.081	15:24
07 Room Air	0.000	15:24

Lot No = 659358
Cyl No = 40
Exp Date = 09/03/2011
County = 30 Oper No. = 068019


Operator Signature
LORI E. FLATEN

Remarks:

Form 106-I8000

80-004939
P. 63 of 63
SM