



ETHANOL GAS STANDARD CYLINDER REPORT

OFFICE OF ATTORNEY GENERAL
CRIME LABORATORY DIVISION
Toxicology Section/Breath Alcohol Program
SFN 59282 (10-2013)

Chemical Test Operator Name (Print) <i>Andrew P. Eisenschenk</i>		
Location <i>Wahpeton City PD</i>	Intoxilyzer® Serial Number <i>80-005958</i>	
Gas Lot Number <i>03417080A3</i>	Gas Cylinder Number <i>029</i>	Gas Expiration Date <i>3-5-2019</i>

Check When Done:

- 1. Scan/Enter Gas Cylinder Information (Level 1, Function S).
- 2. Perform an ACA Test (Level 1, Function C).
Write in the ACA Test Results (Reported to 3 Digits, Ex. 0.081).
 - A. *0.079* AC
 - B. *0.079* AC
 - C. *0.080* AC
- 3. Complete the Top Portion of the Intoxilyzer® Record (SFN50496, Form 120-G) and Place it by the Intoxilyzer® for Use.
- 4. File Previous Intoxilyzer® Record (SFN50496, Form 120-G) at the Intoxilyzer® Location at the Agency.
- 5. Send the Following to the Crime Laboratory:
 - A. Ethanol Gas Standard Cylinder Report (SFN59282, Form 105-G).
 - B. ACA Test Record.

Chemical Test Operator Signature <i>[Signature]</i> 1109	Date <i>09-19-17</i>
Reviewed By (Crime Laboratory Use Only) <i>Roberta Mungo Nimmo</i>	Date <i>09-22-17</i>

Intoxilyzer Test Record and Checklist
NDOAG Crime Lab. Div., Bismarck, ND 58501

CMI, Inc. Intoxilyzer Alcohol Analyzer
North Dakota Model 8000 SN 80-005958
Location = WCPD 8164.13.00 06/09
09/19/2017 21:00

DRY CAL CHECK

Test	AC	Time
01 Room Air	0.000	21:01
02 Std. Gas	0.079	21:01
03 Room Air	0.000	21:02
04 Std. Gas	0.079	21:02
05 Room Air	0.000	21:02
06 Std. Gas	0.080	21:03
07 Room Air	0.000	21:03

Lot No = 03417080A3
Cyl No = 29
Exp Date = 03/05/2019
County = 27 Oper No. = 130409


Operator Signature
ANDREW EISENSCHENK

Remarks: ACC New Cylinder