

ETHANOL GAS STANDARD CYLINDER REPORT NORTH DAKOTA OFFICE OF ATTORNEY GENERAL CRIME LABORATORY DIVISION-TOXICOLOGY SECTION/BREATH ALCOHOL PROGRAM SFN 59282 (08/2018)

Chemical Test Operator Name (Print) Kevin C. Eldridge			
Location		Intoxilyzer® Serial Number	
DKPD		80-006689	
Gas Lot Number	Gas Cylinder Number	•	Gas Expiration Date
14323080A4	40		06/05/2025

Check When Done:

1. Scan/Enter Gas Cylinder Information (Level 1, Function S).

2. Perform an ACA Test (Level 1, Function C).

Write in the ACA Test Results (Reported to 3 Digits, Ex. 0.081).

- A. 0.079 AC
- B. 0.078 AC
- C. 0.079 AC

3. Complete the Top Portion of the Intoxilyzer® Record (SFN50496, Form 120-G) and Place it by the Intoxilyzer® for Use.

1/24. File Previous Intoxilyzer® Record (SFN50496, Form 120-G) at the Intoxilyzer® Location at the Agency.

5. Send the Following to the Crime Laboratory:

- A. Ethanol Gas Standard Cylinder Report (SFN59282, Form 105-G).
- B. ACA Test Record.

1	
Chemical Test Operator Signature	Date 1/30/24
Reviewed By (Crime Laboratory Use Only)	Date 31Jan2024

Intoxilyzer Test Record and Checklist NDOAG Crime Lab. Div., Bismarck, ND 58501

CMI, Inc. IntoxilyzerAlcohol AnalyzerNorth Dakota Model 8000SN 80-006689Location = DKPD8164.14.00 09/1601/30/202415:40

	DRY	CAL CHECK	
Test		AC	Time
01 Room 02 Std. 03 Room 04 Std. 05 Room 06 Std. 07 Room	Gas Air Gas Air Gas	0.000 0.079 0.000 0.078 0.000 0.079 0.000	15:41 15:41 15:42 15:42 15:43 15:43 15:44

Lot No = 14323080A4Cyl No = 40Exp Date = 06/05/2025County = 45

Oper No. = 130935

Signature Operator

KEVIN ELDRIDGE

Remarks:

Form 106-18000