

BREATH ALCOHOL EQUIPMENT
REPAIR AND MAINTENANCE

Instrument: 8600 Serial Number: 80-003065 Location: TOXL

1. Instrument repairs/maintenance performed:

CEE ^{DS} replaced external battery, DS framed battery

2. Does the instrument require further testing?
If Yes, continue.
If No, sign and date below.

Yes or No No

3. If needed, set the time, date, and location.

4. Does the flow need to be calibrated?
If Yes, attach paperwork.

Yes or No

5. Does the optical bench need to be calibrated?
If Yes, attach test records.

Yes or No

6. Does the gas regulator need to be calibrated?

Yes or No

PSI gauge reading _____ PSI display reading _____

Set instrument to Wet Bath and run tests:

7. Low AC. Use < 0.03 AC in ACA mode. Attach test record.

Sim SN: _____ Lot #: _____ AC: _____

8. Linearity Test. Use ≥ 0.25 AC in ACA mode. Attach test record.

Sim SN: _____ Lot #: _____ AC: _____

Set instrument to Gas and run tests:

9. Print test. Attach test record. _____

10. Interferent Check. Use a 0.10 AC ethanol plus 0.05% acetone in ABA mode.
Attach test record. _____

Sim SN: _____ Lot #: _____ AC: _____

11. RFI Check. Run in CMS mode. Key radio during any room air or subject test.
Attach test record. _____

12. Calibration Check. Use a valid 0.080 AC Ethanol Gas Standard. Run three
calibration sets in ACA mode. Attach test records. _____

Lot No. _____ Cylinder No. _____ Expiration Date _____

Test 1 _____

Test 1 _____

Test 1 _____

Test 2 _____

Test 2 _____

Test 2 _____

Test 3 _____

Test 3 _____

Test 3 _____

Average _____

D. Shanaver
Field Inspector's Signature

21 June 16
Date

Charles E. Eden
Reviewed by

24 JUNE 2016 ✓
Date