



ETHANOL GAS STANDARD CYLINDER REPORT

OFFICE OF ATTORNEY GENERAL
CRIME LABORATORY DIVISION
Toxicology Section/Breath Alcohol Program
SFN 59282 (10-2013)

| | | |
|---|--|--------------------------------------|
| Chemical Test Operator Name (Print) <i>Kennelly, Ben</i> | | |
| Location <i>JAME Stutsman County Corrections</i> | Intoxilyzer® Serial Number <i>80-005361</i> | |
| Gas Lot Number <i>33913080A4</i> | Gas Cylinder Number <i>17</i> | Gas Expiration Date <i>1-1-16</i> |

Check When Done:

- 1. Scan/Enter Gas Cylinder Information (Level 1, Function S).
- 2. Perform an ACA Test (Level 1, Function C).
Write in the ACA Test Results (Reported to 3 Digits, Ex. 0.081).
 - A. 0. 079 AC
 - B. 0. 079 AC
 - C. 0. 079 AC
- 3. Complete the Top Portion of the Intoxilyzer® Record (SFN50496, Form 120-G) and Place it by the Intoxilyzer® for Use.
- 4. File Previous Intoxilyzer® Record (SFN50496, Form 120-G) at the Intoxilyzer® Location at the Agency.
- 5. Send the Following to the Crime Laboratory:
 - A. Ethanol Gas Standard Cylinder Report (SFN59282, Form 105-G).
 - B. ACA Test Record.

| | |
|---|----------------------------|
| Chemical Test Operator Signature <i>B. Kennelly</i> | Date <i>8-7-14</i> |
| Reviewed By (Crime Laboratory Use Only) <i>Deb Kashner</i> | Date <i>12 Aug 2014</i> |


Intoxilyzer Test Record and Checklist
NDOAG Crime Lab. Div., Bismarck, ND 58501

CMI, Inc. Intoxilyzer Alcohol Analyzer
North Dakota Model 8000 SN 80-005361
Location = JAME 8164.13.00 06/09
08/07/2014 16:15

DRY CAL CHECK

| Test | AC | Time |
|-------------|-------|-------|
| 01 Room Air | 0.000 | 16:16 |
| 02 Std. Gas | 0.079 | 16:16 |
| 03 Room Air | 0.000 | 16:17 |
| 04 Std. Gas | 0.079 | 16:17 |
| 05 Room Air | 0.000 | 16:18 |
| 06 Std. Gas | 0.079 | 16:18 |
| 07 Room Air | 0.000 | 16:19 |

Lot No = 33913080A4
Cyl No = 17
Exp Date = 01/01/2016
County = 47 Oper No. = 050708


Operator Signature
BENJAMIN KENNELLI

Remarks:
2nd ACA due to RFI detected on 1st