### OFFICE OF ATTORNEY GENERAL CRIME LABORATORY DIVISION

Toxicology Section/Breath Alcohol Program Intoxilyzer® 8000 Inspection

## **INTOXILYZER® 8000 INSPECTION**

Intoxi	lyzer® 8000 Serial Number: 80-006493 Location: Tox L
Α.	General Setup and Checks:  1.
В.	Tests (Sign and attach test records):  X Configure simulator for the following tests (Level 1,S).  Wet Calibration Check  a. X Low AC (Level 1,C): Known Value ≤ 0.03 AC: O·O2 O AC  Sim. Ser #: MP306! Lot #: 201810D Exp. Date: /o·24-20  b. X High AC (Level 1,C): Known Value ≥ 0.25 AC: O·30 O AC  Sim. Ser #: MP3069 Lot #: 201902 D Exp. Date: 2·20·21
	Configure dry gas standard for the following tests (Level 1,S).
	2. Interferent Check (Level 1,B): Known Value: 0.10 AC + 0.05% Acetone Sim. Ser #: DR345 Lot #: ICS 6 Exp. Date: NA    Display reads "Interferent Detect"
C.	Remarks/Maintenance: ANNUAL INSPECTION NEW EXTERNAL BATTERY
	trument is acceptable to be used in the field.  Analyst Signature  A A A
2	
<evie< td=""><td>wed by Date</td></evie<>	wed by Date

02/18

Issuing Authority - CEE

SN 80-006493

Uploaded 6/10/2020 CEE

CMI, Inc. Intoxilyzer Alcohol Analyzer
North Dakota Model 8000 SN 80-006493
Location = TOXL 8164.14.00 09/16
06/03/2020 11:56

\*\*\*\*\*\*\* Printer Test \*\*\*\*\*\*\*\*

abcdefghijklmnopqrstuvwxyz1234567890-=|
ABCDEFGHIJKLMNOPQRSTUVWXYZ!@#\$%^&\*() +?

abcdefghijklmnopqrstuvwxyz1234567890-=|
ABCDEFGHIJKLMNOPQRSTUVWXYZ!@#\$%^&\*()\_+?

Current Instrument Setup

Data Entry Mode: Enabled Start Test Sequence: DABACABA Display Prelim Rslt? Yes Display Third Digit? Yes Inhib Printer(Y/N)? No Display Volume? No Disable On Memfull? Yes # of Print Copies?
Select Std (D/W/I)? 1 Dry Standard Value? 0.080 Standard Lot #? 05620080A1 Standard Cyl #? 34 Standard Expiration? 04/05/2022 Oper No? 666666

Flow Cal. Date: 05/23/2018 Slope 640 Intercept -624033

IR Calibration Date: 05/23/2018
3um 9um

Oth Coef(\*100): -19857 -14695 1st Coef(\*100): 263752 135087 2nd Coef(\*100): 3253 1458 H2O adj(mg/l\*10k): 643 483

\*\*\*\*\*\*\* Printer Test End \*\*\*\*\*\*\*\*

Operator Signature CHARLES EDER

Remarks:

CMI, Inc. Intoxilyzer North Dakota Model 8000 Location = TOXL 06/03/2020

Alcohol Analyzer SN 80-006493 8164.14.00 09/16 11:59

## WET CAL CHECK

Test	AC	Time
01 Room Air	0.000	12:00
02 Std. Sol.	0.019	12:00
03 Room Air	0.000	12:01
04 Std. Sol.	0.019	12:02
05 Room Air	0.000	12:02
06 Std. Sol.	0.019	12:03
07 Room Air	0.000	12:03

08 Sim Temp = 34.0°C

Simul Ser No = MP3061 Std Sol No = 201810D

County = 08

Oper No. = 666666

Operator Signature CHARLES EDER

Remarks:

LOW AC

CMI, Inc. Intoxilyzer North Dakota Model 8000 Location = TOXL 06/03/2020

Alcohol Analyzer SN 80-006493 8164.14.00 09/16 12:05

# WET CAL CHECK

Test	AC	Time
01 Room Air	0.000	12:05
02 Std. Sol.	0.301	12:06
03 Room Air	0.000	12:07
04 Std. Sol.	0.302	12:07
05 Room Air	0.000	12:08
06 Std. Sol.	0.302	12:09
07 Room Air	0.000	12:09

08 Sim Temp = 34.0°C

Simul Ser No = MP3069 Std Sol No = 201902D

County = 08

Oper No. = 666666

Operator Signature CHARLES EDER

H164 AC

Remarks:

0.300 AC Form 106-I8000

CMI, Inc. Intoxilyzer Alcohol Analyzer
North Dakota Model 8000 SN 80-006493
Location = TOXL 8164.14.00 09/16
06/03/2020 12:10

Test	AC	Time
01 Room Air	0.000	12:11
02 *Subject Test	INT*	12:12
03 Room Air	0.000	12:12

\*Invalid Test

Interferent Detected

Sub Name = DISCOVER, THE SPIRIT

Sub DOB = 02/01/1992

Sub Sex = Female

Weight = 150

Test = DUI

Cit = INTERFERENT

Dr. Lic. = ND/DIS921456

Lot No = 05620080A1

Cyl No = 34

Expiration Date = 04/05/2022

County = 08

Oper No. = 666666

Operator Signature CHARLES EDER

Remarks:

Interferent Check 0.10AC+0.05% ACETONE

CMI, Inc. Intoxilyzer Alcohol Analyzer
North Dakota Model 8000 SN 80-006493
Location = TOXL 8164.14.00 09/16
06/03/2020 12:12

Test	AC	Time
01 Diagnostic	OK	12:13
02 Room Air	0.000	12:14
03 *Subject Test	RFI*	12:14
04 Room Air	0.000	12:14

<sup>\*</sup>Invalid Test Inhibited - RFI

Sub Name = DISCOVER, THE SPIRIT

Sub DOB = 02/01/1992

Sub Sex = Female Weight = 150
Test = DUI Cit = RFI CHECK

Dr. Lic. = ND/DIS921456

Lot No = 05620080A1

Cyl No = 34

Expiration Date = 04/05/2022

County = 08 Oper No. = 666666

I followed the Approved Method and the instructions displayed by the Intoxilyzer in conducting this test.

Operator Signature CHARLES EDER

Remarks:

CMI, Inc. Intoxilyzer
North Dakota Model 8000
Location = TOXL
06/03/2020

Alcohol Analyzer SN 80-006493 8164.14.00 09/16 12:15

#### DRY CAL CHECK

Test	AC	Time
01 Room Air	0.000	12:16
02 Std. Gas	0.083	12:16
03 Room Air	0.000	12:17
04 Std. Gas	0.082	12:17
05 Room Air	0.000	12:18
06 Std. Gas	0.082	12:18
07 Room Air	0.000	12:18

Lot No = 05620080A1

Cyl No = 34

Exp Date = 04/05/2022

County = 08

Oper No. = 666666

Operator Signature

Remarks:

Form 106-I8000

0.080AC

CMI, Inc. Intoxilyzer
North Dakota Model 8000
Location = TOXL
06/03/2020

Alcohol Analyzer SN 80-006493 8164.14.00 09/16 12:19

## DRY CAL CHECK

Test	AC	Time
01 Room Air	0.000	12:20
02 Std. Gas	0.082	12:20
03 Room Air	0.000	12:21
04 Std. Gas	0.081	12:21
05 Room Air	0.000	12:21
06 Std. Gas	0.082	12:22
07 Room Air	0.000	12:22

Lot No = 05620080A1

Cyl No = 34

Exp Date = 04/05/2022

County = 08

Oper No. = 666666

Operator Signature
CHARLES EDER

ALIBLATION CUECLE

Remarks:

0.080 AC

CMI, Inc. Intoxilyzer
North Dakota Model 8000
Location = TOXL
06/03/2020

Alcohol Analyzer SN 80-006493 8164.14.00 09/16 12:23

### DRY CAL CHECK

Test	AC	Time
01 Room Air	0.000	12:23
02 Std. Gas	0.082	12:23
03 Room Air	0.000	12:24
04 Std. Gas	0.082	12:24
05 Room Air	0.000	12:25
06 Std. Gas	0.082	12:25
07 Room Air	0.000	12:26

Lot No = 05620080A1

Cyl No = 34

Exp Date = 04/05/2022

County = 08

Oper No. = 666666

Operator Signature CHARLES EDER

Remarks: (ALBRATION Chee

0.080AC