



ETHANOL GAS STANDARD CYLINDER REPORT

NORTH DAKOTA OFFICE OF ATTORNEY GENERAL

CRIME LABORATORY DIVISION-TOXICOLOGY SECTION/BREATH ALCOHOL PROGRAM

SFN 59282 (08/2018)

Chemical Test Operator Name (Print) <i>ZALKERY MYERS</i>		
Location <i>MINOT PD 515 2ND AVE SW</i>		Intoxilyzer® Serial Number <i>80-006503</i>
Gas Lot Number <i>08425080A1</i>	Gas Cylinder Number <i>10</i>	Gas Expiration Date <i>05/05/17</i>

Check When Done:

☒ 1. Scan/Enter Gas Cylinder Information (Level 1, Function S).

☒ 2. Perform an ACA Test (Level 1, Function C).

AEN 5-6-25 Write in the ACA Test Results (Reported to 3 Digits, Ex. 0.081).

A. 0.082 AC

B. 0.081 AC

C. 0.082 AC

☒ 3. Complete the Top Portion of the Intoxilyzer® Record (SFN50496, Form 120-G) and Place it by the Intoxilyzer® for Use.

☒ 4. File Previous Intoxilyzer® Record (SFN50496, Form 120-G) at the Intoxilyzer® Location at the Agency.

☒ 5. Send the Following to the Crime Laboratory:

A. Ethanol Gas Standard Cylinder Report (SFN59282, Form 105-G).

B. ACA Test Record.

Chemical Test Operator Signature <i>Z. Myers</i>	Date <i>05/02/25</i>
Reviewed By (Crime Laboratory Use Only) Anna Narehood	Date <i>Anna Narehood</i> 06May2025

Intoxilyzer Test Record and Checklist
NDOAG Crime Lab. Div., Bismarck, ND 58501

CMI, Inc. Intoxilyzer Alcohol Analyzer
North Dakota Model 8000 SN 80-006503
Location = MIPD 8164.14.00 09/16
05/02/2025 14:16

DRY CAL CHECK

Test	AC	Time
01 Room Air	0.000	14:17
02 Std. Gas	0.082	14:17
03 Room Air	0.000	14:18
04 Std. Gas	0.081	14:18
05 Room Air	0.000	14:19
06 Std. Gas	0.082	14:19
07 Room Air	0.000	14:19

Lot No = 08425080A1
Cyl No = 10
Exp Date = 05/05/2027
County = 51 Oper No. = 132576



Operator Signature
ZACKERY MYERS

Remarks:

Form 106-I8000