

State of North Dakota     )  
  )ss  
County of Burleigh        )

I, Charles E. Eder, do hereby certify that I am the duly-appointed State Toxicologist of the State of North Dakota and the official custodian of the records and files of the office thereof, that I have carefully compared the

**SUBMISSION FOR URINES (104-U); UCOND: SUB.7 2/12 (LOT# 11876) (04-05-12)**

hereto attached with the respective original as the same appears of record on file in the Office of the Attorney General, Crime Laboratory Division, in the County of Burleigh, North Dakota and find the same to be a true and correct copy thereof and of the whole thereof. In witness whereof I have set my hand at the city of Bismarck, in said county this:

5<sup>th</sup> day of APRIL, 2012

  
\_\_\_\_\_  
Charles E. Eder, State Toxicologist

State of North Dakota     )  
  )ss  
County of Burleigh        )

On this 5 day of April, 2012, before me personally appeared Charles E. Eder, known to me to be the State Toxicologist for the State of North Dakota, and acknowledged to me that he has executed the same.

Subscribed to and sworn before me this:

5 day of April, 2012

  
\_\_\_\_\_  
Cindy Leingang, Notary Public, State of North Dakota  
My Commission Expires January 11, 2017

(SEAL)



**SUBMISSION FOR URINES (104-U)**

OFFICE OF ATTORNEY GENERAL, CRIME LABORATORY DIVISION  
 2641 East Main Avenue, P.O. Box 937  
 Bismarck, ND 58502-0937 • (701) 328-6159  
 SFN 50159 (02-12)

Kit Lot No.: 11876  
 Kit Exp. Date: NONE

**PLEASE PRINT ALL INFORMATION**

Subject (Last, First, Initial)		Birth Date _____ (Month/Day/Year)	Height _____ Weight _____	Sex: <input type="checkbox"/> Male <input type="checkbox"/> Female
Check One: <input type="checkbox"/> Arrested for DUI/APC <input type="checkbox"/> Other (Specify) _____		Driver's License Number _____		State _____
Specimen: <input type="checkbox"/> Urine <input type="checkbox"/> Other (Specify) _____	Analysis Requested: <input type="checkbox"/> Alcohol <input type="checkbox"/> Drug Screen <input type="checkbox"/> THC Only	Suspected Drugs: _____ _____		
Time Specimen Obtained _____ <input type="checkbox"/> A.M. <input type="checkbox"/> P.M.	Date Specimen Obtained _____ (Month/Day/Year)	County of Arrest _____		
Specimen Submitted By (Name) _____			Submitting Agency _____	
Submitting Agency Address _____		City _____	State _____	Zip Code _____
Remarks _____				

**FOR LABORATORY USE – DO NOT WRITE IN THIS SPACE**

Laboratory Case Number: _____	Received: <input type="checkbox"/> In a Sealed Container <input type="checkbox"/> In a Labeled Urine Container		
Specimen Received From: <input type="checkbox"/> P.O. Box Delivery <input type="checkbox"/> Other (Specify) _____	Specimen Received By (Name): _____		
Time Specimen Received: _____ <input type="checkbox"/> A.M. <input type="checkbox"/> P.M.	Date Specimen Received: _____ (Month/Day/Year)	Remarks _____	

**Arresting Officer: Tear Along the Perforation and Retain Bottom Portion for Your Records.**

**TO BE COMPLETED BY SPECIMEN SUBMITTER**

Subject (Last, First, Initial)	Time Specimen Obtained: _____ <input type="checkbox"/> A.M. <input type="checkbox"/> P.M.	Date Specimen Obtained: _____ (Month/Day/Year)
Specimen Sealed By (Last, First, Initial)	Time Specimen Sealed: _____ <input type="checkbox"/> A.M. <input type="checkbox"/> P.M.	Date Specimen Sealed: _____ (Month/Day/Year)

**CHECK EACH STEP PERFORMED**

**NOTE: If submitting for Drug Analysis Only (not alcohol), begin with STEP 3.**

**SAMPLE DISPOSAL WILL OCCUR 12 MONTHS AFTER ANALYSIS REPORTING DATE.**

- STEP 1  Instruct the subject to void.
- STEP 2  Establish a minimum 20 minute waiting period.
- STEP 3  Open an intact kit.
- STEP 4  Observed white powder in the specimen container.
- STEP 5  Collect the sample directly into the specimen container. Do not discard powder. Transferring of sample from one receptacle to another is not recommended.
- STEP 6  Instruct the subject to fill the specimen container to about 3/4 full. Take necessary precautions to avoid contamination.
- STEP 7  Fill in the label and place it over the top and down the sides of the specimen container.
- STEP 8  Insert the specimen container into the Ziploc bag provided and seal the bag.
- STEP 9  Insert the completed top portion of this form into the kit box.
- STEP 10  Place the bag containing the specimen in the kit box.
- STEP 11  Close the kit box and seal it with the completed kit box shipping seal provided.
- STEP 12  Complete the return address on the kit box top.

**WARNING:  
SCREW LID ON  
TIGHTLY**

I certify that all information given in this section is true and correct.

Signed \_\_\_\_\_

IF SENDING BY MAIL, AFFIX POSTAGE.

*Charles E. ...* 05 APR 12

UCOND: SUB.7 2/12